

I use glossy laser paper, as I have it and it works OK. Probably any good slick paper will work fine, slicker the better. We want as few holes in the mask as possible. When printing make sure you turn scaling to "None"

Clean the circuit card, Use an Iron with no steam on highest setting

After ironing on. Just soak the whole shebang in water and let the paper fall apart. Use a tooth brush to help scrub the paper from the small areas and don't worry if the paper stays on the large area, like the pads. Just get the white area parts clean.

Etch as normal or IAW the kits instructions.

Lacquer thinner will remove the toner, Nothing else I tried would but LT did a easy and nice job.

